




Spare Parts | Ersatzteile | Pièces de rechange | Ricambi |
 Varaosat | Reservdelar

Pos.	°C	Art.no.
1	45	180 602
1	55	180 603
1	61	180 604
1	72	180 605
1	80	180 606



Amb. temp.



* 45°C - 55°C Max. 95°C

ThermoVar®

LK 825



Registered
Design

INSTRUCTION MANUAL
 BEDIENUNGSANLEITUNG
 MANUEL D'INSTRUCTION
 MANUALE DI ISTRUZIONI
 ASENNUS- JA KÄYTTÖOHJE
 INSTRUKTIONSMANUAL

 LK Armatur

 LK Armatur

Art.nr: 148872 • 1409

LK ARMATUR AB
 Garnisonsgatan 49 • SE-254 66 Helsingborg •
 Sweden
 Tel: +46 (0)42-16 92 00 • Fax: +46 (0)42-16 92 20
 info@lkarmatur.se • order@lkarmatur.se
 www.lkarmatur.se

 youtube.com/lkarmatur

